


#### 1. Programming your personal code

The code of your terminal is 0000 by default. To select or change your personal code:











Enter the present code

Enter the new code

#### 2. Programming your personal directory

Your personal directory contains up to 12 numbers (0 to 9, \* and #).





















Number to programme
















Directory

Numeric key on which you want to programme the number

Personal directory numbers		
0	0	8
0	9	9
0	6	<b>3</b>
€	0	0

#### 3. Programming a function on an unassigned key

The list of programmable functions is given in your user manual.



#### 4. Selecting your ringer tune

key

Terminal idle:














Select the ringer from the 16 options (successive presses)

Adjust the volume

Return to idle



(xx Msg Voice)

**1** 0 oκ

**1** 0 0 0 €

Telephone Feature	Code	How to activate
Transfer call	R	R Extension Hang up
Immediate Forward	#60	#60 Extension Hang up
Cancel Forwarding	#64	#64 Hang up
Automatic Call Back	5	Call Extension (busy) press 5 Hang up
Cancel automatic Call Back	#67	Press #67 Hang up
Busy Camp On	6	Call Extension (busy) press 6 Hear Music
Password Modification	#59	#59 Old Password(****) New Password (****)
Pad Lock	#80	Press #80 Hang up
Cancel Pad Lock	#80	Press #80 Password Hank up
Waiting Call Consultation	#74	A Conversation B Press R Press #74 Conversation
		A Call Extension B Press R Call Extension C
Three Party Conference	3	Press R Press 3 Conversion 3 Party
Wake-up	#81	Press #81 HH:mm:ss Hang up
Cancel wake-up	#82	Press #82 Hang up